


	INTAKE	EXHAUST
ADVERTISED DURATION	284°	280°
ACTUAL CAM LIFT (in/mm)	.450" / 11.43mm	.430" / 10.92mm
ROCKER ARM RATIO	1.73:1	1.73:1
CENTERLINE	108°	114°
LOBE SEPERATION	111°	
DURATION AT 0.050" CAM	212°	208°
DURATION AT 0.050" VALVE	230°	226°
VALVE CLEARANCE	.000" / 0mm HYDRAULIC	.000" / 0mm HYDRAULIC
RECOMMENDED SPRING KIT	BC0100 or BC0120	

CAMSHAFT TIMING AT 0.050" VALVE LIFT	OPEN	CLOSES
	INTAKE	7° BTDC
EXHAUST	47° BBDC	1° BTDC



**NOTES**

BC does not recommend using synthetic oil during break-in or operation. Follow OEM manufacturer's torque sequence and specifications. Use liberal amount of aftermarket engine assembly lube during installation. Check follower or bucket surfaces for abnormal wear and/or scuffing. On initial start-up and break-in run engine at 1500-2500 rpm for 20 minutes. **Camshafts damaged by improper installation, excessive spring pressure or retainers contacting valve guides or seals are void from warranty. Not legal for sale or use on emission controlled motor vehicles.**

